



Prier Products, Inc.  
4515 E. 139th Street  
Grandview, MO 64030 USA  
800-362-9055 Fax 800-362-1463  
[www.PRIER.com](http://www.PRIER.com)

***The Prier C-69 Burner Bar is designed for use as a starter for burning wood in the fireplace. It is not designed or intended for use with Ceramic or Manufactured Logs. For Manufactured Log Application, a shutoff valve is required by plumbing & mechanical codes.***

#### ***Installation:***

1. Select a location in the firebox for the installation of the C-69 Burner Bar. The burner bar has three openings for flexible installation. Select the desired inlet, either left, right or bottom, and using high heat sealant and the enclosed two steel plugs, seal the 2 female NPT tappings you will not use. Using a 3/4" hole saw, cut a hole in the firebox at the appropriate spot for gas supply line. For L.P. Gas Installations, see below.
2. Using 1/2" black iron pipe, connect the outlet of the previously installed gas valve to the inlet of the C-69 burner bar. Using an approved firebox mortar, seal the area where the gas line enters the firebox.

#### ***For L.P. Gas Installations:***

Insert the L.P. Gas Adapter (Prier Part Number 514-0001) into the supply inlet of the C-69 Burner Bar, and connect to the previously installed gas valve as described above.

#### ***Operation:***

1. Operation of the C-69 Log Lighter is simple and provides natural wood burning fires without the inconveniences of kindling and newspaper.
2. Load hardwood logs into the fireplace, on an approved fireplace grate over the C-69 Burner Bar. Being certain the flue is open, light a small amount of newspaper as a "pilot fire" and place it under the logs and over the C-69 Burner Bar. Close fireplace doors!
3. Insert Key into the gas valve and slowly turn counter-clockwise until gas begins flowing through the valve and into the firebox, igniting from the "pilot fire." Adjust the flame from the C-69 Burner Bar by slightly opening or closing the gas valve.
4. After the logs are lit, usually no more than a few minutes, turn the gas valve clockwise until the valve shuts completely. *Remove the Key.* Keep the Key in an area that is not accessible to children or unauthorized users. *Never* store the Hearth Key in the C-64 Gas Valve.

#### ***For L.P. Gas Installations:***

***BY ITS NATURE L.P. GAS (PROPANE) IS HEAVIER THAN AIR, AND WILL NOT DISPERSE AS NATURAL GAS WILL. PLEASE USE THESE EXTRA PRECAUTIONS WHEN USING L.P. GAS.***

1. Do not open valve without a "pilot fire" in the fireplace.
2. Be certain valve is closed tightly after each use
3. Close valve immediately to extinguish Burner Bar flame after Logs are lit.

#### ***Maintenance:***

The C-69 Burner Bar requires very little maintenance and provides years of reliable service. With regular cleanings of ash from the firebox, the orifices in the burner should not clog. Should they clog, using a paper clip or a wire, clean each hole in the burner bar.

**If you have any questions about this or any Prier product, call our technical service department at 800-362-1466.**

890-0001